

# EasyPond Plus Guide

# Thank you for purchasing a PondXpert EasyPond Plus System, all you need to create a filtration system for your pond.

#### Pond Filtration System - Set Up Guide

- 1) The pump is submerged under the water.
- 2) The pump pushes water via a hose to the filter inlet.
- 3) The filter then cleans the water.
- 4) The clean water then exits the filter outlet.
- 5) Water returns to the pond under pressure.

This filtration cycle continuously keeps the pond water clean, oxygenated, and healthy.

#### **Current EasyPond Sets**

Pump and Filter Set	Pump	Filter	Hose and Clips
EasyPond Plus 2000	PondXpert MightyMite 2000	PondXpert SpinClean 4500	
EasyPond Plus 3000	PondXpert MightyMite 2500	PondXpert SpinClean 4500	
EasyPond Plus 4500	PondXpert MightyMite 3000	PondXpert SpinClean 4500	
EasyPond Plus 6000	PondXpert Ultraflow 3600	PondXpert SpinClean 6000	25mm x 5m Hose
EasyPond Plus 8000	PondXpert Ultraflow 5300	PondXpert SpinClean 8000	4x 25mm Clips
EasyPond Plus 9000	PondXpert Ultraflow 6000	PondXpert SpinClean 12000	
EasyPond Plus 12000	PondXpert Ultraflow 8000	PondXpert SpinClean 12000	
EasyPond Plus 20000	PondXpert Ultraflow 12000	PondXpert SpinClean 20000	
EasyPond Plus 25000	PondXpert Ultraflow 14000	PondXpert SpinClean 30000	32mm x 5m Hose
EasyPond Plus 30000	PondXpert Ultraflow 16000	PondXpert SpinClean 40000	4x 32mm Clips

### Pump Set Up

Both pumps provided are extremely easy to set up, as they are already complete when you receive the units. The only jobs you will need to complete are to connect the filter to your electricity supply and connect the hosetails.

Please note: None of our pumps or filters are supplied with plugs. This is due to the UK building regulations. Please see our blog post for more information. Special care must be taken during electrical installation, and we always recommend that our customers consult a qualified electrician for assistance.

#### **PondXpert MightyMite / Ultraflow Pump Notes**

Both pumps are filter pumps designed to push dirty water to a filter only, with there being no option to attach a fountain.

#### **PondXpert MightyMite Pumps**

The MightyMite pump will be supplied with several different sized hosetails. Simply identify the correct hosetail for the hose you are using and attach the hosetail onto the Pump's casing. You can then connect the hose onto the hosetail and fasten it with a hose clip. This can then be connected to the filter at the other end of the hose.



PondXpert MightyMite

#### **PondXpert Ultraflow Pumps**

Simply screw the supplied stepped hosetail onto the outlet as seen on the image to the right. You can then connect the pond hose over the hosetail and fasten it down with a hose clip. This can then be connected to the filter at the other end of the hose.

Please Note: The Ultraflow pumps are supplied with an 'alternative inlet'. This is only to be used if you are drawing water from a skimmer. In all other situations, use the inlet guard to block off part of the strainer cage. Only use the hosetail that has the large blue nut holding it onto the cage. The normal outlet and alternative inlet cannot be used at the same time.



#### Hose clips prevent leaks

It is seen as an essential within the pond world that hose clips are used. This is to prevent any leakages caused by the pressure of the water flow in the hose when the pump is switched on and provide a watertight seal. The hose clips are supplied with the EasyPond Plus kits.

#### **Performance Tips:**

It is considered good practice to raise the pump between 1-2" from the bottom of the pond. This will help improve the efficiency of the pump by preventing blockages and maximising water flow.

For maximum flow performance (reduced friction loss) it is recommended that the lowest unused section of all pump and filter hosetails be removed if possible.

Contact Number: 01642 370888 Pondkeeper Email: info@pondkeeper.co.uk

## PondXpert SpinClean Set Up

The pressurised filters provided are extremely easy to set up, as they are already complete when you receive the units. The only jobs you will need to complete are to connect the filter to your electricity supply and connect the hosetails.

The filter supplied is a pressurised box unit which can be placed away from the pond and the outlet can be directed to a feature, waterfall or straight back into the pond. The SpinClean filters provide UV, media and biological filtration which allow the water drawn in from the pump to be separated from any debris; therefore, providing cleaner water back into the pond.

Please note: None of our pumps or filters are supplied with plugs. This is due to the UK building regulations. Please see our <u>blog post</u> for more information. Special care must be taken during electrical installation, and we always recommend that our customers consult a qualified electrician for assistance.



- 1) The hose attached to the pump outlet needs to be connected to the filter inlet hosetail, which is the clear hosetail located to the right of the blue dial.
- 2) The waste filter outlet should be attached to a hose which is positioned to a flower bed or drain as this will drain away dirty water during a back flush (quick interval cleaning). The outlet pipe is the black hosetail located in front of the blue dial.
- 3) The last hosetail; the outlet allows the cleaned water to re-enter the pond. This can either be straight to the main pond via a hose or a waterfall. The waste outlet is located to the left of the blue dial.

#### **SpinClean Maintenance**

The blue switch to the top of the SpinClean allows you to move between the filter's functions. The function is easily selected by turning to the selected function.

- 1) Turn your pump off and ensure that the blue switch is facing towards the waste pipe.
- 2) Turn your pump back on. While the easy clean feature is active, the handle on top of the filter can be rotated to turn the filters inside; allowing more debris to be removed from the filter.
- 3) Turn the pump off and return the dial to its original position. Your pump can then be turned back on.

#### **Performance Tips:**

**Please Note:** It is often best to use the same size outlet as the inlet. For example, if the inlet pipe is 25mm, it is best to use 25mm on the outlet as well.

For maximum flow performance (reduced friction loss) it is recommended that the lowest unused section of all pump and filter hosetails be removed if possible. It is also good practice to tip box filters forward slightly, by raising the inlet side. This can improve filtration.



PondXpert SpinClean 4500 - 40000



## **Pump Spare Parts**

Please see below for a full list of spare parts for each Pump provided across the EasyPond Plus range. A comprehensive list of our spares can be viewed through our <u>Spares Page</u>.

PondXpert MightyMite Pumps	Spare	Product Code
	PondXpert MightyMite 2000 Impeller	SP-PXMM2000IMP
	PondXpert MightyMite 2500 Impeller	SP-PXMM2500IMP
	PondXpert MightyMite 3000 Impeller	SP-PXMM3000IMP
	PondXpert MightyMite Hosetail Set	SP-PXMM25HSTAIL
PondXpert Ultraflow Pumps	Spare	Product Code
	PondXpert Ultraflow 3600 Impeller	SP-UF3600IMP
	PondXpert Ultraflow 5300 Impeller	SP-UF5300IMP
	PondXpert Ultraflow 6000 Impeller	SP-UF6000IMP
	PondXpert Ultraflow 8000 Impeller	SP-UF8000IMP
	PondXpert Ultraflow 12000 Impeller	SP-UF12000IMP
	PondXpert Ultraflow 16000 Impeller	SP-UF16000IMP
	PondXpert Ultraflow 3000-6000 Hosetail Set	SP-PXUFHSTAIL36
	PondXpert Ultraflow 8000-16000 Hosetail Set	SP-PXUFHSTAIL10-16
	PondXpert Ultraflow Inlet Guard	SP-PXULBLANKCAP
	PondXpert Ultraflow Cage 3000-8000	SP-PXULCAGE

## Filter Spare Parts

Please see below for a full list of spare parts for each Filter provided across the EasyPond Plus range. A comprehensive list of our spares can be viewed through our <u>Spares Page</u>.

сотргене	Spare	Product Code
	11w Single-Ended UVC Bulb	UVCBL011SB
	PondXpert SpinClean 4500 Replacement Foams	SP-PXSC-4500FULLSET
	PondXpert SpinClean 4500 Quartz Sleeve	SP-PXSC4500-QZ
	PondXpert SpinClean 4500 Ballast	SP-PXSC4500-UVC
PondXpert SpinClean 4500	PondXpert SpinClean 4500 UVC & Lid	SP-PXSC4500LIDUVC
	PondXpert SpinClean 4500 Bio Media Wheel	SP-PXSC4500MEDIA
	PondXpert SpinClean 4500 O-Ring Set	SP-PXSC4500ORING
	PondXpert SpinClean 4500 Base Plate	SP-PXSCBASEPLATESM
	PondXpert SpinClean 4500 Base Plate Screw	SP-PXSCBASESCREWSM
	PondXpert SpinClean 4500 Lid Clamp	SP-PXSPIN45CLASP
	PondXpert SpinClean 4500 Hosetail Set	SP-PXSC4500HZ
	Spare	Product Code
	13w Single-Ended UVC Bulb	UVCBL013HB
	PondXpert SpinClean 6000 Replacement Foams	SP-PXSC-6000FULLSET
	PondXpert SpinClean 6000 Quartz Sleeve (13w)	SP-PXSC6-8-12000-QZ
	PondXpert SpinClean 6000 Ballast (13w)	SP-PXSC06000-UVC2019
PondXpert SpinClean 6000	PondXpert SpinClean 6000 UVC & Lid (13w)	SP-PXSC6000LIDUVC
	PondXpert SpinClean 6000 O-Ring Set (13w)	SP-PXSC6000ORINGNEW
	PondXpert SpinClean 6000 Hosetail Set	SP-PXSC4500HZ
	PondXpert SpinClean 6000 Lid Clamp	SP-PXSC-CLAMP
	PondXpert SpinClean 6000 Clamp Tab	SP-PXSC-CLAMPT
	Spare	Product Code
	13w Single-Ended UVC Bulb	UVCBL013HB
	PondXpert SpinClean 8000 Replacement Foams	SP-PXSC-8000FULLSET
	PondXpert SpinClean 8000 Quartz Sleeve (13w)	SP-PXSC6-8-12000-QZ
	PondXpert SpinClean 8000 Ballast	SP-PXSC08000-UVC
PondXpert SpinClean 8000	PondXpert SpinClean 8000 UVC & Lid	SP-PXSC8000LIDUVC
	PondXpert SpinClean 8000 O-Ring Set	SP-PXSC8000ORING
	PondXpert SpinClean 8000 Hosetail Set	SP-PXSCMEDHZ
	PondXpert SpinClean 8000 Lid Clamp	SP-PXSC-CLAMP
	PondXpert SpinClean 8000 Clamp Tab	SP-PXSC-CLAMPT
	PondXpert SpinClean 8000 Foam Bracket	SP-PXSCA-FOAMBR-MED
	Spare	Product Code
	13w Single-Ended UVC Bulb	UVCBL013HB
	PondXpert SpinClean 12000 Replacement Foams	SP-PXSC-12000FULLSET
	PondXpert SpinClean 12000 Quartz Sleeve (13w)	SP-PXSC6-8-12000-QZ
	PondXpert SpinClean 12000 Ballast (13w)	SP-PXSC12000-UVC2019
B	PondXpert SpinClean 12000 UVC & Lid (13w)	SP-PXSC12000LID
		SP-PXSC12000ORINGNEW
DandVnort ChinClass 12000	PondXpert SpinClean 12000 O-Ring Set (13w)	3F-FA3C120000KINGINLW
PondXpert SpinClean 12000	PondXpert SpinClean 12000 O-Ring Set (13w)  PondXpert SpinClean 12000 Hosetail Set	SP-PXSCMEDHZ
PondXpert SpinClean 12000		
PondXpert SpinClean 12000	PondXpert SpinClean 12000 Hosetail Set	SP-PXSCMEDHZ
PondXpert SpinClean 12000	PondXpert SpinClean 12000 Hosetail Set PondXpert SpinClean 12000 Base Plate	SP-PXSCMEDHZ SP-PXSCBASEPLATEMED
PondXpert SpinClean 12000	PondXpert SpinClean 12000 Hosetail Set PondXpert SpinClean 12000 Base Plate PondXpert SpinClean 12000 Base Plate Screw	SP-PXSCMEDHZ SP-PXSCBASEPLATEMED SP-PXSCBASESCREWMED
PondXpert SpinClean 12000	PondXpert SpinClean 12000 Hosetail Set PondXpert SpinClean 12000 Base Plate PondXpert SpinClean 12000 Base Plate Screw PondXpert SpinClean 12000 Lid Clamp	SP-PXSCMEDHZ SP-PXSCBASEPLATEMED SP-PXSCBASESCREWMED SP-PXSC-CLAMP

Contact Number: 01642 370888 Pondkeeper Email: info@pondkeeper.co.uk

	Spare	Product Code
	24w Single-Ended UVC Bulb	UVCBL024SB
	PondXpert SpinClean 20000 Replacement Foams	SP-PXSC-20000FULLSET
	PondXpert SpinClean 20000 Quartz Sleeve	SP-PXSC20000-QZ
PondXpert SpinClean 20000	PondXpert SpinClean 20000 Ballast (24w)	SP-PXSC20000-UVC
	PondXpert SpinClean 20000 UVC & Lid	SP-PXSC20000LIDUVC
	PondXpert SpinClean 20000 O-Ring Set	SP-PXSC20000ORING
	PondXpert SpinClean 20000 Hosetail Set	SP-PXSCMEDHZ
	PondXpert SpinClean 20000 Tub	SP-PXSC20BASE
	PondXpert SpinClean 20000 Base Plate	SP-PXSCBASEPLATEMED
	PondXpert SpinClean 20000 Base Plate Screw	SP-PXSCBASESCREWMED
	PondXpert SpinClean 20000 Lid Clamp	SP-PXSC-CLAMP
	PondXpert SpinClean 20000 Clamp Tab	SP-PXSC-CLAMPT
	PondXpert SpinClean 20000 Foam Bracket	SP-PXSCA-FOAMBR-MED
	Spare	Product Code
	36w Single-Ended UVC Bulb	UVCBL036SB
	PondXpert SpinClean 30000 Replacement Foams	SP-PXSC-30000FULLSET
	PondXpert SpinClean 30000 Quartz Sleeve	SP-PXSC30-QZ
	PondXpert SpinClean 30000 Ballast	SP-PXSC30000-UVC
	PondXpert SpinClean 30000 UVC & Lid	SP-PXSC30000LIDUV
DandVisort CainClass 20000	PondXpert SpinClean 30000 O-Ring Set	SP-PXSC30000ORING
PondXpert SpinClean 30000	PondXpert SpinClean 30000 Hosetail Set	SP-PXSC30000HZ
	PondXpert SpinClean 30000 Tub	SP-PXSC30BASE
	PondXpert SpinClean 30000 Base Plate	SP-PXSC30000BASEPLATE
	PondXpert SpinClean 30000 Base Plate Screw	SP-PXSC30000BASESCREW
	PondXpert SpinClean 30000 Lid Clamp	SP-PXSPIN30CLASP
	PondXpert SpinClean 30000 Clamp Tab	SP-PXSC-CLAMPT
	PondXpert SpinClean 30000 Foam Bracket	SP-PXSCA-FOAMBR-LRG
	Spare	Product Code
	55w Single-Ended UVC Bulb	UVCBL055SB
	PondXpert SpinClean 40000 Replacement Foams	SP-PXSC-40000FULLSET
	PondXpert SpinClean 40000 Quartz Sleeve	SP-PXSC40-QZ
	PondXpert SpinClean 40000 Ballast	SP-PXSC40000-UVC
	PondXpert SpinClean 40000 UVC & Lid	SP-PXSC40000LIDUVC
DandVisort ChinClass 40000	PondXpert SpinClean 40000 O-Ring Set	SP-PXSC40000ORING
PondXpert SpinClean 40000	PondXpert SpinClean 40000 Hosetail Set	SP-PXSC30000HZ
	PondXpert SpinClean 40000 Tub	SP-PXSC40BASE
	PondXpert SpinClean 40000 Base Plate	SP-PXSC40000BASEPLATE
	PondXpert SpinClean 40000 Base Plate Screw	SP-PXSC40000BASESCREW
	PondXpert SpinClean 40000 Lid Clamp	SP-PXSPIN30CLASP
	PondXpert SpinClean 40000 Clamp Tab	SP-PXSC-CLAMPT