


General Information

Forming a vacuum in the upper part of the tube allows the fish to swim above the natural water level. The water level is above the normal water surface due to this vacuum. The fish tower has an opening on the bottom through which the fish can swim. The fish tower allows the fish to stay above the water surface. In the fish Viewing Tower, the water temperature is warmer due to the sun's rays. This warm water attracts the fish. The Fish Viewing Tower is designed so the fish can swim in and out of the opening at any time. You can choose a suitable position in your garden pond. As soon as the water has warmed up, the first fish will swim into it. Tip: With some food, the fish initially find their way into the lookout tower more easily


Installation

In order to place the Fish Observation Tower correctly in your garden pond, you must follow the installation instructions prescribed by us.

1. Choose a suitable location for the Tower inside your pond. Note: erected the tower will need a flat level surface on which to stand (at least 25 x 25cm wide). A stone slab may be suitable. We suggest choosing a location near the edge of the pond that is relatively easy to reach for maintenance.
2. Tilt the Fish Observation Tower so that it is completely below the surface of the water and can fill up completely with water. Once the Fish Observation Tower is completely filled with water you can turn it over and place it vertically in the water. Pay attention to a straight, non-slip surface. The water in the fish observation tower will warm up and attract the fish in your pond.



Alternative Installation method if a pond vacuum cleaner is available.



Tip: Push the suction hose with the tube lying down to the lid, then set it up first:

- 1) Place the Fish Observation Tower vertically in your garden pond by hand.
- 2) With the help of a pond vacuum, you can suck the remaining air from the fish tower.

Tip : While you remove the pond vacuum, it should continue to run. Otherwise, the air will escape back into the tube.

Attention:

- Protect from frost – remove Tower from Pond early autumn.
- Place the pond fish outlook tower in your pond so that it is not exposed too much and not too little sun. Too much sunlight promotes algae growth. Too little solar radiation does not warm the water in the observation tower strong enough. Recommended is a daily sun exposure of about 3-4 hours.
- Please note for cleaning Please use a soft sponge or a microfiber towel to clean the fish tower, so as not to scratch the acrylic.

Limited Warranty

This product is guaranteed for a period of 12 months from the date of purchase for material or manufacturing defects. The guarantee covers the substitution of defective parts. However, the guarantee is considered null and void in the case of improper use, improper handling or negligence on the part of the buyer. If your pondXpert Tower fails please take it back to the retail outlet from where it was purchased. You will be required to take your receipt/proof of purchase with you. This does not affect your statutory rights.

pondXpert Fish Viewing Tower 65cm Instructions

Thank you for purchasing this product from us. In order to enjoy the device for a long time and to avoid any risk, please read this manual carefully. You will find information on warranty cases and services at the end of this manual.

The Fish Viewing Tower is intended for use in the garden pond and may only be used for the purposes described in this manual.

Warning: The fish tower draws the attention of children. Please do not underestimate the risk of drowning, and do not let children play unsupervised near bodies of water. Installation of this product may involve entry into the pond water so should only be performed by a competent adult ideally supervised by another person.

Technical Data

Material of Viewing Tower	UV-Resist Acrylic
Thickness acrylic glass	3mm
Height of observation tower	40cm
Diameter of observation tower	20cm
Material of Bracket	Metal
Height of Bracket	30cm
Total Height after assembly	65cm

PondXpert
A3 Bertley Avenue
Billingham
TS23 4BU
UK
01542 370898 www.pondxpert.co.uk



Your appliance contains valuable materials which can be recovered or recycled. Leave it at a local civic waste collection point.